


Initials specifications required for the Tube Furnace

Working Temperature	0-1700 C
Temperature control	PID automatic control
No. of programs	3-10
Tube	Quartz Tube

A handwritten signature in blue ink, consisting of stylized, overlapping letters and lines, positioned below the table.